

OPERATING PROCEDURE

- **Always** Check daily before use that the power supply cable, plug and sockets are in good condition; check for visible signs of damage (do not use if damaged)
- **Always** Follow the correct procedure when filling the water reservoirs and waste tank
- **Always** The use of disposable gloves and aprons is recommended with this machine
- **Never** allow any part of the machine to be immersed in water
- **Never** allow inexperienced, untrained or unauthorised people access to the machine

Operating Procedures on the SteamForce 3 (Vac)



Lift the cap to the water reservoir, insert the red funnel and fill with ONLY cold clean tap water.

NEVER fill with detergent



Plug the machine into a suitable electrical socket and press the ON/OFF switch to the ON position



Press the boiler switch button to the ON position and allow the machine to heat up



After approx. 7-8 minutes until the green "Ready" light stops flashing.
The machine is now



Connect the steam hose to the steam socket



Connect the extension tubes to the pistol grip if required and Select the required accessory and push firmly onto the pistol grip until it clicks into place



Set the steam volume required using the steam regulator



Push the red button into the "ON" position and press the trigger on the pistol grip to release the steam.



When the red water reservoir light illuminates, stop operation straight away and refill the water tank



When using detergent and the orange chemical light illuminates; stop operation and refill the chemical tanks

Operating Procedures on the SteamForce 3 (Vac) (cont)

Addition of chemical



If chemical is required, remove black cap and fill the chemical bottles with an approved chemical



Firmly connect the chemical filler tubes from the chemical bottle to the rear of the machine



Select the appropriate hose and connect to the front socket. With the steam only hose press the orange button into the ON position. Chemical will be released periodically when the trigger is pressed; releasing the steam



On the Steam & Vacuum hose; chemical dosage is controlled via the pistol grip. Depress and hold the button on top of the pistol grip whilst simultaneously pressing the pistol grip



Using the vacuum on the SteamForce 3 (Vac)



Connect the steam & vacuum hose to the front socket then connect the black vacuum pipe to the vac unit by sliding the red clip to the left. Push the hose into the vac socket and release the red clip to lock in to position



Ensure the Vac unit is connected to the rear of the machine (bottom left corner)



Switch the vacuum unit on using the white switch at the top.



The vacuum is controlled via the pistol grip. Push the right side button once to use the vacuum. Press again to turn vacuum off.

Note:

In accordance with PSSR 2000 the machines should be serviced within 14 month intervals.